


#### Guide to features (rear panel):



**1. Input:** Plug one end of the connecting cable (included) into this jack. Plug the other end of the connecting cable into the jack on the back of the Model Two radio marked "SUB". This jack accepts a 1/8" male mini plug.

**2. 12-16V DC:** Use this input to operate the Model Subwoofer from a DC power supply.

**3. 120V-60Hz:** Connect the supplied power cord to this jack.

#### Placement:

Since bass frequencies are non-directional, the Model Subwoofer can generally be placed anywhere on the floor in the listening room. Placement close to a wall or in the corner of a room will yield more bass. However, be sure there is enough ventilation to prevent heat build-up from the internal amplifier. The Model Subwoofer is not a small table or footrest and should not be used as such. Placing the subwoofer up high, such as on a bookshelf or a counter, is not recommended.

The Model Subwoofer is not magnetically-shielded and caution should be exercised when using this unit near a computer monitor or television set. We recommend the Model Subwoofer be a minimum of 10" from a computer monitor or TV.

#### Cleaning:

Never use any harsh cleansers or solvents on your Model Subwoofer. Avoid using spray-on waxes. A liquid wood polish will usually yield better results. The face may be cleaned with a slightly damp, soft cloth. Take care not to rub too hard.

If you are using the Model Subwoofer with Tivoli Audio's Model Two radio, note that since the cabinet laminate is natural wood, there may not be an exact color/grain match between the subwoofer and the Model Two's cabinet. You may also notice the wood darken over time.

#### Warranty:

Tivoli Audio manufactures its products to very high standards and we are confident our products will perform well for many years. Accordingly, we warranty all of our products against manufacturing defects in material and workmanship to the original owner, for a period of one year from the original date of purchase.

This warranty does not extend to damage caused by improper use/installation, faulty ancillary equipment, modifications, unauthorized repair, shipping damage or loss, abuse, accidents, use on improper voltage/current, lightning or other acts of God, normal wear and tear, or purchases from unauthorized dealers. Proof of purchase as evidence the unit was purchased from an authorized dealer within the warranty period may be required for warranty service. Should service be necessary, DO NOT return the product without first contacting your dealer or Tivoli Audio. This warranty is non-transferable.

Please resist the temptation to take apart your radio. There are no user serviceable parts, and any attempt at modifying or repairing your radio will void the warranty.

Tivoli Audio will not pay for loss of time, inconvenience, loss of use of your product, or damaged caused by this product.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Some states do not allow limitations on implied warranties or the exclusion of consequential damages, therefore, these restrictions may not apply to you.

If you purchased an extended warranty from your dealer and service is required after the manufacturer's warranty has expired, you should contact your dealer to obtain service.

Please complete and return the enclosed card within 30 days of purchase to register your product for warranty coverage, or you may register on-line at: [www.tivoliaudio.com](http://www.tivoliaudio.com)

For more information about other exciting audio products by Tivoli, including our table radio companion models, please visit our web sites or contact us directly.

#### Specifications:

<b>Model:</b>	<b>Model Subwoofer</b>
Type:	Bass-reflex
Driver:	1 x 5 1/4" bass driver
Amplifier power:	20 watts
Dimensions:	6 1/2" H x 9 1/2" W x 6 5/16" D
Weight:	5.75 lbs

*All specifications subject to change without notice.*

#### OWNER'S MANUAL

# Model Subwoofer




**For more information about other exciting audio products by Tivoli Audio, please visit our web sites or contact us directly:**

Tivoli Audio  
1 Broadway, Suite 600  
Cambridge, Massachusetts 02142  
Tel: 877-297-9479  
[www.tivoliaudio.com](http://www.tivoliaudio.com)  
[www.tivolidesign.com](http://www.tivolidesign.com)

**TIVOLI**  
AUDIO™

**TIVOLI**  
AUDIO™



This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

## IMPORTANT SAFETY INSTRUCTIONS

### READ INSTRUCTIONS

All the safety and operating instructions should be read before operating this product.

### RETAIN INSTRUCTIONS

The safety and operating instructions should be retained for future reference.

### HEED WARNINGS

All warnings on the product and in the operating instructions should be adhered to.

### FOLLOW INSTRUCTIONS

All operating and use instructions should be followed.

### CLEANING

Unplug the product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

### ATTACHMENTS

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

### WATER AND MOISTURE

Do not use this product near water – for example, near a bath tub, wash bowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool and the like.

### ACCESSORIES

Do not place this product on an unstable cart, stand, tripod, bracket or table. The product may fall, causing serious damage to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

### VENTILATION

Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

### POWER SOURCES

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

### GROUNDING OR POLARIZATION

This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

### POWER CORD PROTECTION

Power-supply cords should be routed so that they are not likely to be walked-on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

### LIGHTNING

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet. This will prevent damage to the product due to lightning and power-line surges.

### OVERLOADING

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

### OBJECT AND LIQUID ENTRY

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts which could result in fire or electric shock. Never spill liquid of any kind on the product.

### SERVICING

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

### DAMAGE REQUIRING SERVICE

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged.
- If liquid has been spilled, or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
- If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance – this indicates a need for service.

### REPLACEMENT PARTS

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

### SAFETY CHECK

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

### HEAT

The product should be situated away from heat sources such as radiators, heat registers, stoves or other products (including amplifiers) that produce heat.

Congratulations on purchasing Tivoli Audio's Model Subwoofer. We are particularly proud of the extraordinary performance and value this subwoofer represents. The Model Subwoofer provides deep, powerful bass despite its diminutive size. Its wood cabinet, color, and size make it a perfect companion piece to Tivoli Audio's Model Two radio. We wish you many years of pleasurable listening.

In order to take full advantage of what your new subwoofer is capable of, please take a moment to fully read this owner's manual. If you have any questions do not hesitate to contact your dealer or Tivoli Audio directly. It is a good idea to save the carton and original packing should you ever need to ship your subwoofer, as shipping damage is not covered by the factory warranty.

On behalf of all of us, thank you for choosing Tivoli Audio, and enjoy your new subwoofer!

### About Tivoli Audio:

Tivoli Audio was started by Tom DeVesto with the goal of bringing simple to use, high- quality audio products to the consumer at reasonable prices. His long professional association with Henry Kloss includes co-founding Cambridge SoundWorks. As the CEO and head of research and development at his former company, he was responsible for the development of many of the best-selling home entertainment products on the market today. He also held senior management positions in product development for both Advent and Kloss Video.


### Packed with your Tivoli Audio Model Subwoofer you should find:

- 1 9' power cord
- 1 Model Subwoofer
- 1 15' connecting cable
- 1 Warranty registration card

Please contact your dealer or Tivoli Audio if any of these items are missing.

Tivoli Audio  
1 Broadway, Suite 600  
Cambridge, Massachusetts 02142  
Tel: 877-297-9479  
www.tivolioaudio.com  
www.tivolidesign.com

### Guide to features (front panel):



**1. Auto On/Off:** In the Auto position, the light will glow red (STANDBY) and change to green (ON) once a signal is detected. If the subwoofer does not receive a signal after approximately 10 minutes, it will return to STANDBY and the light will change back to red.

**2. Power Indicator:** See above.

**3. Level:** Controls the subwoofer's volume level.